

OWNER'S MANUAL Model: 16008900630

Please carefully read this entire manual before operating your new treadmill.

TABLE OF CONTENTS

Product Registration	3
Important Safety Instructions	4
Important Electrical Instructions	5
Important Operation Instructions	6
Assembly instructions	10
Folding Instructions	14
Transport Instructions	14
Operation of Your New Treadmill	15
Bluetooth® Connectivity	19
Programmable Features	21
General Maintenance	28
Service Checklist - Diagnosis Guide	31
Manufacturer's Limited Warranty	38



CONGRATULATIONS ON YOUR NEW TREADMILL AND WELCOME TO THE SOLE FAMILY!

Thank you for your purchase of this quality treadmill from Dyaco Canada Inc. Your new treadmill has been manufactured by one of the leading fitness manufacturers in the world and is backed by one of the most comprehensive warranties available. Dyaco Canada Inc. will do all we can to make your ownership experience as pleasant as possible for many years to come.

If you have any questions about your new Sole product or questions about the warranty, contact Dyaco Canada Inc. at 1-888-707-1880.

Please take a moment at this time to record below the name of the dealer, their telephone number and the date of purchase for easy contact in the future. We appreciate your confidence in **SOLE** and we will always remember that you are the reason we are in business. Please go to www.dyaco.ca/warranty.html and complete the online warranty registration.

Dyaco Canada Inc.	
Name of Dealer:	
Telephone Number of Dealer:	
Purchase Date:	

PRODUCT REGISTRATION

RECORD YOUR SERIAL NUMBER

Please record the Serial Number of this fitness product in the space provided below.

Serial Number:	



REGISTER YOUR PURCHASE

Please visit us at www.dyaco.ca/warranty.html to register your purchase.

IMPORTANT SAFETY INSTRUCTIONS

WARNING - Read all instructions before using this equipment.

DANGER - To reduce the risk of electric shock disconnect your SOLE treadmill from the electrical outlet prior to cleaning and/or service work.

WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons, install the treadmill on a flat level surface with access to a 120-volt, 15-amp grounded outlet with only the treadmill plugged into the circuit.

DO NOT USE AN EXTENSION CORD UNLESS IT IS A 14AWG OR BETTER, WITH ONLY ONE OUTLET ON THE END: DO NOT ATTEMPT TO DISABLE THE GROUNDED PLUG BY USING IMPROPER ADAPTERS, OR IN ANY WAY MODIFY THE CORD SET.

A serious shock or fire hazard may result along with computer malfunctions. See Grounding Instructions, page 5.

- Do not operate treadmill on deeply padded, plush or shag carpet. Damage to both carpet and treadmill may result.
- Do not block the rear of the treadmill. Provide a minimum of 3 1/2 feet clearance between the rear of the treadmill and any fixed object.
- Keep children under the age of 13 away from this machine. There are obvious pinch points and other caution areas that can cause harm.
- Keep hands away from all moving parts.
- Never operate the treadmill if it has a damaged cord or plug. If the treadmill is not working properly, call your dealer.
- Keep the cord away from heated surfaces.
- Do not operate where aerosol spray products are being used or where oxygen is being administered. Sparks from the motor may ignite a highly gaseous environment.
- Never drop or insert any object into any openings.
- Do not use outdoors.
- To disconnect, turn all controls to the off position, remove tether cord, then remove the plug from the outlet.
- Do not attempt to use your treadmill for any purpose other than for the purpose it is intended.
- The pulse sensors are not medical devices. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The pulse sensors are intended only as exercise aids in determining heart rate trends in general.
- Use handrails provided; they are for your safety.
- Wear proper shoes. High heels, dress shoes, sandals or bare feet are not suitable for use on your treadmill. Quality athletic shoes are recommended to avoid leg fatigue.
- This equipment is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the equipment by a person responsible for their safety.

Remove tether cord after use to prevent unauthorized treadmill operation.

SAVE THESE INSTRUCTIONS - THINK SAFETY!

IMPORTANT ELECTRICAL INSTRUCTIONS

WARNING!

NEVER remove any cover without first disconnecting AC power. If voltage varies by ten percent (10%) or more, the performance of your treadmill may be affected. Such conditions are not covered under your warranty. If you suspect the voltage is low, contact your local power company or a licensed electrician for proper testing.

NEVER expose this treadmill to rain or moisture. This product is NOT designed for use outdoors, near a pool or spa, or in any other high humidity environment. The temperature specification is 40 degrees C, and humidity is 95%, non-condensing (no water drops forming on surfaces). **Circuit breakers:** Avoid AFCI/GFCI circuit breakers if possible. These breakers may trip occasionally during use because of the high inrush currents from the treadmill drive motor. This

occasionally during use because of the high inrush currents from the treadmill drive motor. This condition is an issue with all treadmills and other products with large motors or electric heating elements like ovens.

New laws in your area may require these breakers. If you do have these breakers and outlets in your home and are experiencing nuisance tripping, you should check to see if there are any other devices plugged into the same circuit like fluorescent lights with electronic ballasts, coffee maker, space heater, etc. Optimally the treadmill should be the only device plugged into the circuit.

Our treadmills have surge suppressors built in to help avoid nuisance tripping. We have tested several AFCI/GFCI breakers and outlets with our products that do not trip when only the treadmill is connected. Brands we have tested are: Eaton (Cutler Hammer Series), Leviton (Smart lock pro) and Schneider Electric (Canadian home series).


GROUNDING INSTRUCTIONS

This product must be grounded. If the treadmill should malfunction or breakdown, grounding provides a path of least resistance for electric current, reducing the risk of electric shock. This product is equipped with a cord having an equipment-grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

DANGER - Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product if it will not fit the outlet; have a proper outlet installed by a qualified electrician.

This product is for use on a nominal 110-volt circuit and has a grounding plug that looks like the plug illustrated below. A temporary adapter that looks like the adapter illustrated below may be used to connect this plug to a 2-pole receptacle as shown below if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet, (shown below) can be installed by a qualified electrician. The green colored rigid ear-

lug, or the like, extending from the adapter, must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by a metal screw.



IMPORTANT OPERATION INSTRUCTIONS

- **NEVER** operate this treadmill without reading and completely understanding the results of any operational change you request from the computer.
- Understand that changes in speed and incline do not occur immediately. Set your desired speed on the computer console and release the adjustment key. The computer will obey the command gradually.
- **NEVER** use your treadmill during an electrical storm. Surges may occur in your household power supply that could damage treadmill components. Unplug the treadmill during an electrical storm as a precaution.
- Use caution while participating in other activities while walking on your treadmill; such as watching television, reading, etc. These distractions may cause you to lose balance or stray from walking in the center of the belt; which may result in serious injury.
- **NEVER** mount or dismount the treadmill while the belt is moving. **SOLE** treadmills start at a very low speed and it is unnecessary to straddle the belt during start up. Simply standing on the belt during slow acceleration is proper after you have learned to operate the unit.
- Always hold on to a handrail or hand bar while making control changes (incline, speed, etc.).
- Do not use excessive pressure on console control keys. They are precision set to function properly with little finger pressure. Pushing harder is not going to make the unit go faster or slower. If you feel the buttons are not functioning properly with normal pressure contact your **SOLE** dealer.

SAFETY KEY INSTRUCTIONS

A safety tether cord is provided with this unit and should be used at all times. It is for your safety should you fall or move too far back on the tread-belt. Pulling this safety tether cord will stop tread-belt movement.

To Use:

- 1. Place the safety key into position on the console control head. Your treadmill will not start and operate without this. Removing the safety key also secures the treadmill from unauthorized use.
- 2. Fasten the plastic clip onto your clothing securely to assure good holding power.

 Note: The clip should be attached securely to make certain it does not come off. Be familiar with its function and limitations. The treadmill will stop, depending on speed, with a one to two step coast anytime the safety key is pulled off the console. Use the red Stop switch in normal operation.
- 3. If the console displays "Safety key removed, machine stopped, click Replace the key to Operate", put the Safety key back to continue using the treadmill.

IMPORTANT SAFETY INSTRUCTIONS

READ BEFORE UNPACKING YOUR FOLDING TREADMILL

Serious injury could occur if this folding treadmill is not unpacked properly.

There is a Velcro strap installed around the treadmill base that prevents the treadmill from unfolding accidentally during shipping. If this strap is not removed properly the treadmill could spring open unexpectedly and cause injury if someone is standing near the treadmill when the strap is removed.

To ensure your personal safety during removal of the shipping strap please make sure the treadmill is positioned flat on the ground, in the orientation it would be in if you were using the treadmill. Do not turn the treadmill up on its side while removing the shipping strap. This could cause the treadmill's folding mechanism to spring open. If the end of the Velcro strap (that you need to grab to remove it) happens to be under the treadmill deck, reach under the deck to grab it, but do not tilt the treadmill up to gain access to the strap end.

PREVENTATIVE MAINTENANCE CHART

Vacuum Under Motor Cover & Check Wiring (Every Other Month)	Clean & Inspect Deck for Lubrication (Every Other Month)	Lubricate Deck (Every 90 hours or sooner if dry)	Inspect Belt Tracking (Monthly) Adjust if necessary	Date

F63 ASSEMBLY PACK CHECKLIST

HARDWARE STEP 2



#128. M5 Speed Nuts Clip (2 pcs)

HARDWARE STEP 3




#130. 5/16" x 1/2" Button Head Socket Bolt (8 pcs)

HARDWARE STEP 5



#113. Ø10 x 1.5T Split Washer (4 pcs)




#139. 3/8" x 1-3/4" Button Head Socket Bolt (4 pcs)

HARDWARE STEP 6



#175. 3.5 x 16mm Sheet Metal Screws (4 pcs) 7

<u>HARDWARE STEP 7</u>



#159. 5/16" x 3/4" Button Head Socket Bolt (4 pcs)



#75. Safety Key

8

HARDWARE STEP 8



#120. 5 x 16mm Tapping Screw (2 pcs)



#140. M5 × 10m/m_ Phillips Head Screw (2 pcs)


9

HARDWARE STEP 9




#175. 3.5 x 16mm Sheet Metal Screws (4 pcs)

ASSEMBLY TOOLS



F63 ASSEMBLY INSTRUCTIONS

ASSEMBLY STEP 1



1. Remove the treadmill from the carton and position it aside on a smooth, leveled floor. The rear should be at least 3' from any wall. You must remove the plastic wrap and Styrofoam from beneath the unit before removing the Velcro belt. Tilting the unit sideways after removing the belt may cause the unit to fold and bounce upwards. This can cause serious injury.

ASSEMBLY STEP 2

128

HARDWARE **STEP 2**

#128. M5 Speed Nut Clip (2 pcs)


- 1. Install two Speed Nut Clips (128) on the left and right sides of the Frame Base.
- 2. Slide the Console Mast Covers (64 & 65) onto the console masts. Take note of the orientation.
- 3. Slide the Frame Base Covers (62L & 63R) over the Upright tubes (4 & 5). Connect the Lower Computer Cable (50) to the Middle Computer Cable (49) on the right side of the unit.

Before attaching the hardware in Step 3, make sure the cables you just connected don't get pinched in between the steel tubing. If they do, this may cause issues that prevent the treadmill from operating properly.

ASSEMBLY STEP 3

HARDWARE **STEP 3**


#130. 5/16" x 1/2" Button Head Socket Bolts (8 pcs)



 Attach the Upright Tubes (4 & 5) onto the Frame Base (2) with eight Button Head Socket Bolts (130) by using the Combination M5 Allen Wrench & Phillips Head Screwdriver (131). Do not tighten the bolts completely until Step 7 is finished.

4

ASSEMBLY STEP 4




To complete this step, it is recommended that you find something to rest the console on at an appropriate height or have someone hold the console while you connect the cables.

 Connect the Speed Adjustment Switch Cable (54) to the Speed Cable, Upper (37). Connect the Incline Adjustment Switch Cable (55) to the Incline Cable, Upper (38). Connect the Computer Cable, Middle (49) and Computer Cable, Upper (48). Tuck the excess cable into the handrail tubing to prevent it from getting pinched.

Before attaching the hardware in Step 5, make sure the cables you just connected don't get pinched in between the steel tubing. If they do, this may cause issues that prevent the treadmill from operating properly.

5

ASSEMBLY STEP 5




HARDWARE **STEP 5**

#139. 3/8" x 1-3/4"
Button Head Socket
Bolts (4 pcs)
#113. Ø 10 x 1.5T Split
Washers (4 pcs)

1. Insert the Console Assembly (**52**) into the Upright Tubes (**4 & 5**) and attach with four Button Head Socket Bolts (139) and four Split Washers (**113**). Tighten using the M6 L Allen Wrench (**132**).

6

ASSEMBLY STEP 6




HARDWARE **STEP 6**

#175. 3.5 x 16mm Sheet Metal Screws (4 pcs)

 Attach the Left (64) and Right (65) Console Mast Covers to the top of the Upright Tubes (4 & 5) with four Sheet Metal Screws (175). Tighten with the Combination M5 Allen Wrench & Phillips Head Screwdriver (131). 7

ASSEMBLY STEP 7



HARDWARE STEP 7


#159. 5/16" x 3/4" Button Head Socket Bolts (4 pcs)

#75. Safety Key

- Attach the Handrail Support (26) between the upright tubes (4 & 5) with four Button Head Socket Bolts (159). Tighten bolts firmly.
- 2. Place the Beverage Holder (158) on top of the Handrail Support (26) as shown in the illustration.
- 3. Place the magnet of the safety key (**75**) in between the Start and Stop buttons (if it isn't already attached). *The treadmill will not function without this in place.*
- 4. Check to make sure all bolts and screws are completely tightened.

8

ASSEMBLY STEP 8



HARDWARE **STEP 8**


#120. 5 x 16mm
Tapping Screws (2 pcs)
#140.M5 × 10m/m
Phillips Head Screw(2 pcs

- 1. Finish tightening the button head bolts (from Step 2 and above) that secure the console masts to the frame.
- 2. Attach the Frame Base covers (**62 & 63**) to the Frame Base (**2**) with two Tapping Screws (**120**) and two Phillips Head Screws (**140**). Tighten screws using the Combination M5 Allen Wrench & Phillips Head Screwdriver (**131**).

ASSEMBLY STEP 9

HARDWARE STEP 9

#175. 3.5 x 16mm Sheet Metal Screws (4 pcs)



1. Insert Tablet Holder (177) into the Console Assembly (52) and use Combination M5 Allen Wrench & Phillips Head Screwdriver (131) to tighten four of Sheet Metal Screw (175).

FOLDING INSTRUCTIONS

Do not attempt to move the unit unless it is in the folded and locked position. Be sure the power cord is secured to avoid possible damage. Use both handrails to maneuver the unit to the desired position.

■ TO FOLD THE TREADMILL

Make certain that the treadmill is at minimum incline. Lift the treadmill's running deck until it is secured by the locking telescoping tube assembly in the center back of the base.

■ TO UNFOLD THE TREADMILL

Apply slight forward pressure* on the treadmill running deck with one hand. Pull down the unlocking lever and slowly lower the running deck to the floor. The deck will descend unassisted when it reaches about waist high.

*At the rear roller area to relieve pressure on the locking system.





TRANSPORTATION INSTRUCTIONS

The treadmill is equipped with transport wheels that are engaged when the treadmill is folded. After folding simply roll the treadmill away.

OPERATION OF YOUR TREADMILL

GETTING FAMILIAR WITH THE CONTROL PANEL



GETTING STARTED

Power the treadmill on by plugging it into an appropriate wall outlet, then turn on the power switch located at the front of the treadmill below the motor hood. Ensure that the **Safety Key** is installed, as the treadmill will not power on without it (*see assembly step 7 for reference*).



When the power is turned on, a message will scroll across the **Message Window** showing the current software version. Then the **Time** and **Distance Windows** will display Odometer readings for a short time. **Time Window** will show how many hours the treadmill has been in use and the **Distance Window** will show how many miles (or Kilometers if the treadmill is set to metric readings) the treadmill has gone. The treadmill will then enter idle mode, which is the starting point for operation.

Customer Service 1-888-707-1880 Email: customerservice@dyaco.ca

START OPERATION

- 1. Attach the **Safety Key** to wake the display up, if it's not already on.
- 2. Press the **Start** key to begin belt movement. Adjust to the desired speed using the **Speed** ▲/▼ keys on either the console or handgrip. You may also use the speed keys 2, 3, 4, 5, 7, 9 or 12 to adjust the speed.
- 3. To slow down the tread-belt, press and hold the **Speed** ▼ key on the console or handgrip to the desired speed. You may also press the speed adjust keys, 2 through 12.
- 4. To stop the tread-belt, press **Stop** key or pull away **Safety Key**.







PAUSE/STOP/RESET FEATURE

- 1. When the treadmill is running, the pause feature may be utilized by pressing the red **Stop** key once. This will slowly decelerate the tread-belt to a stop. The incline will go to zero percent. The **Time**, **Distance** and **Calorie** readings will hold while the unit is in the pause mode. After 5 minutes the display will reset and return to the startup screen.
- 2. To resume your exercise, while in Pause mode, press the **Start** key. The speed and incline will return to their previous settings.
 - Pause is executed when the **Stop** button is pressed once. If the **Stop** button is pressed for the second time, the program will end, and a workout summary will be displayed. If the **Stop** button is pressed for the third time, the console will return to the idle mode (startup) screen. If the **Stop** button is held down for more than 3 seconds, the console will reset.

INCLINE FEATURE

- Incline may be adjusted any time after belt movement.
- Press and hold the Incline ▲/▼ keys on the console or handgrip to achieve your desired level of effort. You may also choose a more rapid increase / decrease by selecting desired key, 1, 3, 5, 7, 9, 12 and 15, on the left-hand side of console (incline).
- The Incline Window display will indicate incline position as adjustments are made.








Customer Service 1-888-707-1880 Email: customerservice@dyaco.ca

DOT MATRIX CENTER DISPLAY

Eighteen columns of dots – each 8 units high - indicate each segment of a workout for the F63. The dots are only to show an approximate level of effort in speed or incline. They do not necessarily indicate a specific value - only an approximate percent to compare levels of intensity. In operation, the speed/incline dot matrix window will build a profile "picture" as values are changed during a workout. When the word "Speed" is lit above the dot matrix, it indicates that the Speed profile is being displayed. When the word "Incline" is lit above the dot matrix, it indicates the Incline profile is being displayed.

You may change the Dot Matrix profile view between Speed and Incline by pressing the **Enter** button. After pressing **Enter** to view the two profiles, pressing it for the third time will automatically alternate the Speed and Incline displays, showing each one for five seconds.



MESSAGE WINDOW DISPLAY

The **Message Window** will initially display **Program Name**. Each time the **Display** button is pressed, the next set of information will appear. The order of information displayed will be: **Pace, Incline, Laps, Verticle, Segment Time, Max Speed** (in mph), and **Data Scan** mode. In **Data Scan** mode, the displayed information will change every 4 seconds in the **Message Window**.

1/4 MILE TRACK

The 1/4 mile track is displayed around the dot matrix window. The flashing dot indicates your progress. The number of laps you complete are accumulated in the lap counter, which is viewed in the **Message Window**.

CALORIE DISPLAY

Displays the cumulative calories burned at any given time during your workout.


Note: This is only a rough guide used for comparison of different exercise sessions, which cannot be used for medical purposes.

There is an **Audio Input Jack** () on the front of the console and built-in speakers. You may plug any low-level audio source signal into this port. Audio sources include MP3, iPod, portable radio, CD player or even a TV or computer audio signal. There is an audio patch cable included and a headphone jack () for private listening.

PULSE FEATURE

The **Pulse** (**Heart Rate**) **Window** will display your current heart rate in beats per minute during the workout. You must use both stainless steel sensors on the front cross bar to display your pulse or wear the wireless chest strap. The pulse value will display anytime the upper display is receiving a pulse

signal.



TURNING OFF TREADMILL

- 1. The display will automatically turn off, by going into sleep, after 30 minutes of inactivity when in the Pause / Stop mode. Almost all power for the treadmill will be off except for some circuits that are needed to detect if any key is pressed, indicating the console should "wake up". When the console is "asleep" the treadmill draws very little power, for about as much as a television turned off.
- 2. Removing the **Safety Key** is similar to entering "sleep" mode. Turning off the main power switch in the front of the treadmill will completely remove any power.

ATTENTION

Your new console comes configured in an in-store 'Display Mode' of operation, where the console will remain powered on unless the main power switch is turned off. To exit the display mode, for normal operation, press and hold the **Stop**, **Enter** and **Display** keys for 5 seconds; the display will show: Display mode - On. Use any of the **Program**, **Incline** or **Speed** ▲ keys to change the setting to Off then press **Enter**.

Sole App to be used in conjunction with select Apple & Android devices!

In order to help you achieve your exercise goals, Sole has added an exciting new feature to this product. Your new exercise machine comes equipped with a Bluetooth* transceiver that will allow it to interact with selected phones or tablet computers via the Sole Fitness App.

Just download the free Sole Fitness App from the Apple Store or Google Play, and follow the instructions in the App to sync with your exercise machine. This allows you to view current workout data in three different Display screens on your device. You can easily switch back and forth from the workout display view to internet/social media/email sites via icons on the display screen. When your workout is finished, the data is automatically saved to the built-in personal calendar for future reference.

Our new Sole Fitness App also allows you to sync your workout data to one of many fitness cloud sites we support: iHealth, MapMyFitness, Record or Fitbit.

Syncing the App with your exercise machine:

After downloading the App, make sure Bluetooth® is enabled on your device, then tap the icon in the top left corner to search for Sole equipment.



After the equipment is detected, tap Connect. When the App and equipment are synced, the Bluetooth® icon on the equipment's console will light up. You may now start using your new Sole product!

If the treadmill is not connected to the app, the console will display "SYNC" when the workout is over. You can then connect using your phone or tablet to store workout data in the App. The console can only store the last workout data. When the treadmill returns to IDLE MODE, workout data will be erased.

*Note: Your device will need to run on a minimum operating system of iOS 10.1 or Android 6.0 or above for the Sole Fitness App to operate properly.

The exercise equipment's Bluetooth device (BLE 4.0) can also be connected to the Bluetooth wireless heart rate chest strap transmitter (BLE 4.0). The chest strap transmitter can receive signals even when the App is already in use. In order to do such a functional switch, you need to use the heart rate key on the keyboard. Take the following steps to achieve this:

- In idle mode, the heart rate Bluetooth LED on the keypad will not be lit if the Bluetooth function is currently connected with the App.
- 2. In idle mode, press the heart rate key on the keyboard. The Bluetooth LED will light on. This shows that the Bluetooth function is now switched to connect to the Bluetooth wireless heart rate chest strap. You can wear the Bluetooth wireless heart rate chest strap first then commence connection. While in connection, the console will show heart rate value via Bluetooth.
- 3. When the workout is over, the console will automatically switch its Bluetooth connection back to the previously connected App.

The exercise equipment can also play music wirelessly via Bluetooth. Turn on your mobile phone or tablet's Bluetooth function. Search for the name "Bt-speaker" in your device's Bluetooth menu. Tap to connect. Now your device can transmit music to the exercise equipment.


Charge Portable Devices with USB port

USB Port Charging function:

Charge your personal device during your workout using the fitness equipment's on-console USB port.


To charge your mobile electronics make sure the fitness equipment power is on.

- Step 1: Connect your USB charging cable (not included) to the USB Power Port and to your device.
- Step 2: Check to make sure your device icon indicates it is charging.



NOTE:

- * USB charging cable is not included, make sure compatible USB charging cable is being used.
- ** Your device "charging" icon may or may not indicate it is charging. Depending on the amount of current your particular device requires for charging the icon may not be on but your device is still charging, but possibly at a lower charge rate.
- ***The USB port on the console is capable of powering USB devices. It provides up to 5Vdc/1.0 amp of power and meets USB 2.0 regulations. You will not be able to save your workout data to a USB via this port; it is used for charging purposes only.





PROGRAMMABLE FEATURES

The F63 / have ten built-in programs: one Manual program, five preset profiles (**P1-P5**), two user defined programs (**U1** & **U2**) and two Heart Rate programs (**HR1** & **HR2**).

Hill

The **Hill** program simulates going up and down a hill. The workload will steadily increase and then decrease during the program.






Fat Burn


The **Fat Burn** program is designed, as the name implies, to maximize the burning of fat. There are many schools of thought on the best way to burn fat but most experts agree that a lower exertion level that stays at a steady workload is the best. The absolute best way to burn fat is to keep your heart rate at around 60% to 70% of its maximum potential. This program does not use heart rate but simulates a lower, steady exertion workout.






Cardio


The **Cardio** program is designed to increase your cardiovascular function and endurance. This is exercise for your heart and lungs. It will build up your heart muscle and increase blood flow and lung capacity. This is achieved by incorporating a higher level of exertion with slight fluctuations in work.






Strength


The **Strength** program is designed to increase muscular strength in your lower body. This program will steadily increase in workload to a high level and forces you to sustain it. This is designed to strengthen and tone your legs and glutes (muscles of the butt).






HIIT

The **HIIT** program takes you through high levels of intensity followed by periods of low intensity. This program increases your endurance by depleting your oxygen level followed by periods of recovery to replenish oxygen. Your cardiovascular system gets programmed to use oxygen more efficiently this way. This program also forces your body to become more efficient due to spikes in heart rate, between recovery periods. This aids in heart rate recovery from intense activities.






SELECTING A PROGRAM

 Press the Program ▲/▼ keys to view the programs on the screen then press the Enter key to select the program you would like to perform. The display will prompt you through the programming steps or you can just press the Start key to begin the program using the preset program values for age, weight and other program specific information.




- 2. If **Enter** was pressed, the **Message Window** will display **Age**. You may use any of the ▲/▼ keys to adjust your age. After adjusting press the **Enter** key.
 - **Note**: You may press **Start** at any time during the programming to start the program with the information you've already input.
- 3. The **Message Window** will now be displaying a value, which is your body weight. Entering the correct body weight will affect the calorie count. Use any of the ▲/▼ keys to adjust, then press **Enter**.
 - **Calorie Display Note**: No exercise machine can give you an exact calorie count because there are too many factors which determine exact calorie burn for a particular person. Even if someone is the exact same body weight, age and height, their calorie burn may be very different than yours. The **Calorie** display is to be used as a reference only to monitor improvement from workout to workout.
- 4. The Time Window and Message Window will now be displaying a value, which is total workout time desired. Use any of the ▲/▼ keys to adjust, and then press Enter. After adjusting, press the Enter key.
- 5. The Message Window will display the preset max speed of the selected program. Use any of the ▲/▼ keys to adjust, and then press Enter. Each program has various speed changes throughout; this allows you to limit the highest speed the program will reach at its peak.
- 6. Press **Start** to begin the program. The program will begin with a 3 minute warm-up. If you want to bypass this and go directly to the beginning of the program, press **Start** again.



USER PROGRAMS

- 1. Select **User 1** or **User 2** via the **Program △**/**▼** keys then press **Enter**. Note that the dot matrix display portion will have a single row of dots at the bottom (Unless there is a previously stored program). If there is a program stored under the button that is pressed, it will be retrieved. If not, you have the option of programming in your first name. The **Message Window** will display and flash the letter "A". To change it, press the any ▲ key, then "B" will be displayed; if the any ▼ key is pressed, the letter "Z" will be displayed. After selecting the appropriate letter, press **Enter**. The letter "A" will again be displayed and blinking. Repeat the procedure until all letters of your first name are programmed (7 characters maximum). When your name is displayed, press **Stop** and it will be stored under either User 1 or User 2.
- 2. Next the **Message Window** is flashing **Age**. Use the **Incline △**/**▼** keys to adjust. Press **Enter**. This is a must to continue even if age is not adjusted.

INCLINE PROGRAM PROGRAM ENTER SPEED SPEED



- 3. The **Message Window** will now be blinking a body weight value. Enter your body weight and press **Enter**.
- 4. The **Time Window** and **Message Window** will now be blinking a **Time** value. Adjust the **Time** and press **Enter**.
- 5. The first column (segment) will now be blinking. Using the **Speed** ▲/▼ or keys, adjust the speed level to your desired effort for the first segment then press **Enter**. The second column will now be blinking. Repeat the above process until all segments have been programmed. The first column will be blinking again. This is for the incline programming. Repeat the above process to program all segments for incline.
- 6. Press the **Start** button to begin the workout and also save the program to memory.

Note: While in a User program, if you change the speed, all segment speeds from there on will also change. **Examples:** If you increase your current speed 1 mph, the remaining segment speeds will increase by 1 mph. If you decrease your current speed .5 mph, the remaining segment speeds will decrease by .5 mph, etc.

HEART RATE PROGRAMS

Before we get started, a word about Heart Rate:

The old motto, "no pain, no gain", is a myth that has been overpowered by the benefits of exercising comfortably. A great deal of this success has been promoted by the use of heart rate monitors. With the proper use of a heart rate monitor, many people find that their usual choice of exercise intensity was either too high or too low and exercise is much more enjoyable by maintaining their heart rate in the desired benefit range.


To determine the benefit range in which you wish to train, you must first determine your Maximum Heart Rate. This can be accomplished by using the following formula: 220 minus your age. This will give you the Maximum Heart Rate (MHR)for someone of your age. To determine the effective heart rate range for specific goals you simply calculate a percentage your MHR. Your Heart rate training zone is 50% to 90% of your maximum heart rate. 60% of your MHR is the zone that burns fat while 80% is for strengthening the cardiovascular system. This 60% to

80% is the zone to stay in for maximum benefit.

For someone who is 40 years old their target heart rate zone is calculated:

220 – 40 = 180 (maximum heart rate) 180 x 0.6 = 108 beats per minute (60% of maximum) 180 X 0.8 = 144 beats per minute (80% of maximum)

So, for a 40-year-old the training zone would be 108 to 144 beats per minute.



If you enter your age during programming the console will perform this calculation automatically. Entering your age is used for the Heart Rate programs. After calculating your MHR you can decide upon which goal you would like to pursue.

The two most popular reasons for, or goals, of exercise are cardiovascular fitness (training for the heart and lungs) and weight control. The black columns on the chart above represent the MHR for a person whose age is listed at the bottom of each column. The training heart rate, for either cardiovascular fitness or weight loss, is represented by two different lines that cut diagonally through the chart. A definition of the lines' goal is in the bottom left-hand corner of the chart. If your goal is cardiovascular fitness or if it is weight loss, it can be achieved by training at 80% or 60%, respectively, of your MHR on a schedule approved by your physician. Consult your physician before participating in any exercise program.

RATE OF PERCEIVED EXERTION

Heart rate is important but listening to your body also has a lot of advantages. There are more variables involved in how hard you should workout than just heart rate. Your stress level, physical health, emotional health, temperature, humidity, the time of day, the last time you ate and what you ate, all contribute to the intensity at which you should workout. If you listen to your body, it will tell you all of these things.

The rate of perceived exertion (RPE), also known as the Borg scale, was developed by Swedish physiologist G.A.V. Borg. This scale rates exercise intensity from 6 to 20 depending upon how you feel or the perception of your effort.

The scale is as follows: Rating

Perception of Effort

6 Minimal

7 Very, very light

8 Very, very light +

9 Very light

10 Very light +

11 Fairly light

12 Comfortable

13 Somewhat hard

14 Somewhat hard +

15 Hard

16 Hard +

17 Very hard

18 Very hard +

19 Very, very hard

20 Maximal

You can get an approximate heart rate level for each rating by simply adding a zero to each rating. For example, a rating of 12 will result in an approximate heart rate of 120 beats per minute. Your RPE will vary depending up the factors discussed earlier. That is the major benefit of this type of training. If your body is strong and rested, you will feel strong and your pace will feel easier. When your body is in this condition, you are able to train harder and the RPE will support this. If you are feeling tired and sluggish, it is because your body needs a break. In this condition, your pace will feel harder. Again, this will show up in your RPE and you will train at the proper level for that day.

USING HEART RATE TRANSMITTER

How to wear your wireless chest strap transmitter:

- 1. Attach the transmitter to the elastic strap using the locking parts.
- 2. Adjust the strap as tightly as possible as long as the strap is not too tight to remain comfortable.
- 3. Position the transmitter with the SOLE logo centered in the middle of your body facing away from your chest (some people must position the transmitter slightly left of center). Attach the final end of the elastic strap by inserting the round end and, using the locking parts, secure the transmitter and strap around your chest.
- 4. Position the transmitter immediately below the pectoral muscles.
- 5. Sweat is the best conductor to measure very minute heart beat electrical signals. However, plain water can also be used to pre-wet the electrodes (2 ribbed oval areas on the reverse side of the belt and both sides of the transmitter). It's also recommended that you wear the transmitter strap a few minutes before your work out. Some users, because of body chemistry, have a more difficult time in achieving a strong, steady signal at the beginning. After "warming up", this problem lessens. As noted, wearing clothing over the transmitter/strap doesn't affect performance.
- 6. Your workout must be within range distance between transmitter/receiver to achieve a strong steady signal. The length of range may vary somewhat but generally stay close enough to the console to maintain good, strong, reliable readings. Wearing the transmitter immediately against bare skin assures you of proper operation. If you wish, you may wear the transmitter over a shirt. To do so, moisten the areas of the shirt that the electrodes will rest upon.

Note: The transmitter is automatically activated when it detects activity from the user's heart. Additionally, it automatically deactivates when it does not receive any activity. Although the transmitter is water resistant, moisture can have the effect of creating false signals, so you should take precautions to completely dry the transmitter after use to prolong battery life (estimated transmitter battery life is 2500 hours). The replacement battery is Panasonic CR2032.

ERRATIC OPERATION

Caution! Do not use this treadmill for Heart Rate unless a steady, solid Actual Heart Rate value is being displayed. High, wild, random numbers being displayed indicate a problem.

Areas to look for interference which may cause erratic heart rate:

- 1. Microwave ovens, TV's, small appliances, etc.
- 2. Fluorescent lights.
- 3. Some household security systems.
- 4. Perimeter fence for a pet.
- 5. Some people have problems with the transmitter picking up a signal from their skin. If you have problems, try wearing the transmitter upside down. Normally the transmitter will be oriented so the SOLE logo is right side up.
- 6. The antenna that picks up your heart rate is very sensitive. If there is an outside noise source, turning the whole machine 90 degrees may de-tune the interference.
- 7. Loose treadmill console or bolts in the upright tube.
- 8. Another Individual wearing a transmitter within 3' of your machine's console.

If you continue to experience problems, contact your dealer.

WARNING! - DO NOT USE THE HEART RATE PROGRAM IF YOUR HEART RATE IS NOT REGISTERING

HEART RATE CONTROL PROGRAMMING

CAUTION!

Heart Rate Control programs are intended for wireless transmitter chest strap. Do not use **Pulse Grip** bar for **Heart Control**. You must receive a strong/steady value in the **heart rate window** (See Using Heart Rate Transmitter section for instructions on how to use).

The **HR1** program has a default level that is 60% of your projected heart rate maximum. This program is geared for individuals with fat loss as a goal. The **HR2** program has a default of 80% of your projected heart rate maximum. It is geared for individuals with a goal of improving cardiovascular & lung function.

- 1. Select **HR1** or **HR2** via the **Program** keys then press **Enter**.
- 2. The **Message Window** will now be blinking showing user's age. Adjust and press **Enter** or press **Enter** to accept the default value. Adjusting **Age** will change the Target HR value.
- 3. The **Message Window** will be blinking, showing the default user's bodyweight for this pro- gram. You may adjust it and press **Enter** if you want or just press **Enter** to accept the default value.
- 4. Now you are asked to adjust the HR1 or HR2 value. The default is 60% (HR1); (220 age x .60); or 80% (HR2); (220 age x .80). You may select a higher or lower number also. Adjust the number by pressing the Speed ▲/▼ keys and press Enter to continue.
- 5. The **Time Window** and **Message Window** will now be blinking. Adjust the time and press **Enter**.
- 6. Now you are finished editing the settings and can begin your workout by pressing the **Start** key. You can also go back and modify your settings by pressing the **Stop** key to go back one level, or screen.
- 7. If you want to increase or decrease the speed at any time during the program press the **Speed** ▲/▼ keys.
- 8. During the HR program you will be able to scroll through the data in the **Message Window** by pressing the **Display** key. When the program ends the **Message Window** will show a summary of your workout. The summary will be displayed for a short time then the console will return to the start-up display.
- 9. Press **Start** to begin program.

The program will now control the treadmill to steadily increase your heart rate to the target value. This process is automatic and could take upwards of five minutes, depending on how far your HR needs to go and what kind of physical shape you are in. People who are more fit will take longer to reach the target. You can make manual adjustments to the speed throughout the program.

Customer Service 1-888-707-1880 Email: customerservice@dyaco.ca

GENERAL MAINTENANCE

BELT & DECK

Your treadmill uses a very high-efficient low-friction deck. Performance is maximized when the deck is kept as clean as possible. Use a soft, damp cloth, or paper towel, wipe the edge of the belt and the area between the belt edge and the frame. Also reach as far as practical directly under the belt edge. This should be done once a month to extend belt and bed life. A mild soap and water solution along with a nylon scrub brush will clean the top of the textured belt. **Allow to dry before using.**

BELT DUST

This occurs during normal break-in or until the belt stabilizes. Sometimes the black dust from the belt will appear on the floor behind the treadmill, this is normal.


GENERAL CLEANING (Use the chart on Pg. 5 to record your maintenance)

Dirt, dust, and hair can block air inlets and accumulate on the running belt. Please vacuum underneath your treadmill on a monthly basis to prevent excess build-up of dirt that can get sucked up and get into the inner workings under the motor cover. Every other month, you should remove the motor cover and carefully vacuum out dirt and hair that may accumulate. UNPLUG THE POWER CORD BEFORE THIS TASK.

BELT ADJUSTMENTS

Tread-belt Tension Adjustment - Belt tension is not critical for most users. It is very important though for joggers and runners in order to provide a smooth, steady running surface. Adjustment must be made from the rear roller with the M6 L Allen wrench (132) provided in the parts package. The adjustment bolts are located at the end of the step rails as shown in the diagram below. *Note:* Adjustment is through small hole in end cap.

Tighten the rear roller only enough to prevent slippage at the front roller. Turn the tread-belt tension adjusting bolts 1/4 turn each and inspect for proper tension by walking on the belt and making sure it is not slipping or hesitating with each step. When an adjustment is made to the belt tension, you must be sure to turn the bolts on both sides evenly or the belt could start tracking to one side instead of running in the middle of the deck.




DO NOT OVERTIGHTEN – Over tightening will cause belt damage and premature bearing failure. If you tighten the belt a lot and it still slips, the problem could actually be the drive belt - located under the motor cover - that connects the motor to the front roller. If that belt is loose it feels similar to the walking belt being loose. Tightening the motor belt should be done by a trained service person.

TREAD-BELT TRACKING ADJUSTMENT

The treadmill is designed so that the tread-belt remains reasonably centered while in use. It is normal for some belts to drift near one side while in use, depending on a user's gait and if they favor one leg. But if during use the belt continues to move toward one side, adjustments are necessary.

TO SET TREAD-BELT TRACKING

A 6 mm Allen wrench (132) is provided for this adjustment. Make tracking adjustments on the left side bolt. Set belt speed at 3 mph. Be aware that a small adjustment can make a dramatic difference which may not be apparent right away. If the belt is **too close to the left side**, then turn the bolt only a 1/4 turn to the right (clockwise) and wait a few minutes for the belt to adjust itself.



Continue to make 1/4 turns until the belt stabilizes in the center of the running deck. If the belt is **too close to the right side**, turn the bolt counterclockwise. The belt may require periodic tracking adjustment depending on use and walking/running characteristics. Some users may affect tracking differently. Expect to make adjustments as required to center the tread-belt. Adjustments will become less of a maintenance concern as the belt is used. Proper belt tracking is an owner responsibility common with all treadmills.

ATTENTION:

DAMAGE TO THE RUNNING BELT RESULTING FROM IMPROPER TRACKING / TENSION ADJUSTMENTS IS NOT COVERED UNDER THE SOLE WARRANTY.

TREADMILL BELT

The walking belt on your new Sole treadmill is made of the highest quality materials designed to last even under punishing conditions. When a treadmill belt is brand new, and has been in the package for a few months before use, a common occurrence can happen; the area of the belt that wraps around the rollers will take on the shape of the roller. Upon starting the treadmill this shape in the belt causes a thumping sound each time the belt moves past the rollers. Once the treadmill has been used for a few workouts, the belt wears in and the thumping sound goes away. This noise is normal on new higher end belts so there is no need to contact service; the new belt just requires a wear in period. Thank you for choosing Sole and enjoy your new treadmill.

BELT/DECK LUBRICATION

First, you want to clean between the belt and deck to remove any debris that may be trapped. Use a clean, non-fraying rag, t-shirt, or light towel. Halfway between the end of the treadmill and motor cover, shove the garment under the belt until you can grasp it on both sides of the belt. Drag the garment the length of the entire belt 1-2 times. Remove the garment.

Do not lubricate with anything other than Sole Fitness approved lubricant. Your treadmill comes with one tube of "Lube" and extra tubes can be ordered directly from Sole Fitness or your authorized Sole Fitness dealer. You may also use a Lube-n-Walk kit that can be purchased through both aforementioned sellers.

Keeping the deck lubricated at the recommended intervals ensures the longest life possible for your treadmill. If the lubricant dries out, the friction between the belt and deck rises and places undue stress on the drive motor, drive belt and electronic motor control board, which could result in catastrophic failure of these expensive components. Failure to lubricate the deck at regular intervals may void the warranty.

The belt & deck come pre-lubricated and subsequent lubrication should be performed every 90 hours of use or if you notice that the deck is dry. It is recommended that you reach between the belt and deck to verify there is lubrication present, every other month. If you check and there isn't any lubrication present, follow the procedure below even though the "Lube" indicator isn't lit on the console. Otherwise, lubricate when the console's lubrication reminder lights after 90 hours of use. Use the following procedure to apply the silicone lubricant:

- 1. Turn the power switch off and unplug the power cord from the wall outlet
- 2. Measure 18" from the edge of the motor cover; kneel down and reach under the belt approximately 4- 6" from one edge. Squirt a line of lubricant about 1/8" wide x 15" long in an "S" pattern perpendicular to the motor cover.
- 3. Repeat the process on the opposite side.
- 4. Plug the electrical cord back into the outlet and turn the power switch on.
- 5. Walk on the belt at a moderate speed for five minutes to evenly distribute the silicone lube.
- 6. If the "Lube" message appears on the console, perform the following procedure to reset the message:
 - a. To enter the Engineering Mode Menu press and hold down the Start, Stop and Enter keys, then at the same time insert the Safety Key. Keep holding the keys down until the Message Window displays Engineering Mode Menu. Press the Enter button to access.
 - b. Press the **Speed** ▲ button (or **Speed** ▼ button to go backwards) until "Functions" appears; press **Enter**.
 - c. Press the **Speed** ▲ button until "Maintenance" message appears; press **Enter** to reset the lube message.
 - d. Press **Stop** to exit Engineering Mode and resume use of your treadmill.

SERVICE CHECKLIST - DIAGNOSIS GUIDE

Before contacting your dealer for aid, please review the following information. It may save you both time and expense. This list includes common problems that may not be covered under the treadmill's warranty.

PROBLEM

SOLUTION/CAUSE

Display does not light	 Tether cord not in position. Circuit breaker on front grill tripped. Push circuit breaker in until it locks. Plug is disconnected. Make sure plug is firmly pushed into AC household wall outlet. Household circuit breaker may be tripped. Treadmill defect. Contact your SOLE dealer.
Tread-belt does not stay centered Treadmill belt hesitates when walked/run on	The user may be walking while favoring or putting more weight on either the left or right foot. If this walking pattern is natural, track the belt slightly off-center to the side opposite from the belt movement. See General Maintenance section on Tread-belt Tension . Adjust as necessary.
Motor is not responsive after pressing Start	 If the belt moves but stops after a short time and the display shows "E1", run calibration. If you press Start and the belt never moves, then the display shows "E1", contact service.
Treadmill will only achieve approximately 7 mph but shows higher speed on display	This indicates motor should be receiving power to operate. Low AC voltage to treadmill. Do not use an extension cord. If an extension cord is required it should be as short as possible and heavy duty 16 gauge minimum. Low household voltage. Contact an electrician or your SOLE dealer. A minimum of 110 volt AC current is required.
Tread-belt stops quickly/suddenly when tether cord is pulled	High belt/deck friction. See General Maintenance section on lubrication.
Treadmill trips on board 15 amp circuit	High belt/deck friction. See General Maintenance
Computer shuts off when console is touched (on a cold day) while walking/running	Treadmill may not be grounded. Static electricity is "crashing" the computer. Refer to Grounding Instructions.
House circuit breaker trips, but not the treadmill circuit breaker	Check that the treadmill is the only object in the circuit. See "Important Electrical Information" in the front of this manual for more details.

CALIBRATION PROCEDURE

- 1. Remove the Safety Key.
- 2. Press and hold down the **Start** and **Speed** ▲ buttons and at the same time replace the **Safety Key**. Continue to hold the **Start** and **Speed** ▲ keys until the window displays "Factory settings", then press the **Enter** key.
- 3. You will now be able to set the display to show Metric or English settings (Miles vs. Kilometers). To do this, press the **incline** ▲/▼ key to show which you want, then press **Enter**. (The maximum speed value is displayed in the speed window, and the maximum elevation value is displayed in the incline window.)
- 4. Grade return On (This allows the incline to return to zero when **Stop** button is pressed. For sale in Europe, EU standards require this to be off)
- 5. Press **Start** button to begin calibration. The process is automatic; the speed will start up without warning, so do not stand on the belt.

ADJUSTING THE SPEED SENSOR

If the calibration does not pass you may need to check the speed sensor alignment.


- 1. Remove the motor cover hood by loosening the 4 screws that hold it in place (you do not need to remove them completely).
- 2. The speed sensor is located on the left side of the frame, right next to the front roller pulley (the pulley will have a belt around it that also goes to the motor). The speed sensor is small and black with a wire connected to it.
- 3. Make sure the sensor is as close as possible to the pulley without touching it. You will see a magnet on the face of the pulley; make sure the sensor is aligned with the magnet. There is a screw that holds the sensor in place that needs to be loosened to adjust the sensor. Re-tighten the screw when finished.



MAINTENANCE MENU

- Press and hold the **Start**, **Stop** and **Enter** key at the same time, until the display shows "Engineering mode" (it may say maintenance menu, depending on version).
 Press the **Enter** key.
- 2. You can now scroll through the menu using the **Speed** ▲/▼ keys. Use the **Stop** key to return to previous menu selection. The menu selections are:
 - A. **Key Test** Will allow you to test all the keys to make sure they are functioning
 - B. **Display Test** Tests all the display functions
 - C. **Functions** Press **Enter** to access settings, use **Speed △**/**▼** keys to scroll
 - I. **Display Mode** Turn off to have the console power down automatically after 30 minutes of inactivity
 - II. Pause Mode Turned on to allow 5 minutes of pause, turn off to have console pause in definitely
 - III. Maintenance Reset lube message and odometer readings
 - IV. Units Choose from English or Metric display readings
 - V. **Key Tone** Will turn on/off beeping noise that is made when keys are pressed.
 - D. **Security** Allows you to lock the keypad so no unauthorized use of the machine is allowed. When the child lock is enabled, the console will not allow the keypad to operate unless you press and hold the **Start** and **Enter** buttons for 3 seconds to unlock the console.
 - E. Exit

EXPLODED VIEW DIAGRAM



PARTS LIST

Key	Part	Part Description	Q'ty
1	9006301	Main Frame	1
2	9006302	Frame Base	1
3	9006303	Incline Bracket	1
4	9006304	Right Upright	1
5	9006305	Left Upright	1
6	9006306	Console Support	1
7	9006307	Deck Cross Brace	2
8	9006308	Outer Slide	1
9	9006309	Inner Slide	1
10	9006310	Link	1
11	9006311	Link Shaft	1
12	9006312	Shaft Bushing	2
13	9006313	Fastening Bracket	2
14	9006314	Clevis Pin	1
15	9006315	Fastening Bushing	1
16	9006316	Dual Torsion-Spring	1
17	9006317	Release Lever	1
18	9006318	Ø1.8_ChenChin Torsion-Spring	1
19	9006319	Cylinder	1
20	9006320	Drive Belt	1
21	9006321	Front Roller W/Pulley	1
22	9006322	Rear Roller	1
23	9006323	Running Deck	1
24	9006324	Running Belt	1
25	9006325	PVC Handgrip	2
26	9006326	Handrail Support	1
27	9006327	Ø2_Steel Cable Tension Spring	1
28	9006328	Wire Clamp	1
29	9006329	Wire Tie Mount	8
30	9006330	Motor Bottom Cover	1
31	9006331	Steel Cable	1
34	9006334	Drive Motor	1
35	9006335	Incline Motor	1
36	9006336	Motor Controller	1
37	9006337	800m/m_Speed Cable Upper	1
38	9006338	800m/m_Incline Cable Upper	1
39	9006339	400m/m_Handpulse Wire	1
40-1	9006340-1	400m/m_Handpulse W/Cable Assembly(L)	1
40-2	9006340-2	400m/m_Handpulse W/Cable Assembly(R)	1
41	9006341	Handpulse End Cap	2
42	9006342	Breaker	1
43	9006343	Power Socket	1
44	9006344	AC Electronic Module	1
45	9006345	100m/m_Connecting Wire (Black)	1
=	3000343		1

Key	Part	Part Description	Q'ty
46	9006346	300m/m_Connecting Wire (White)	1
47	9006347	300m/m_Connecting Wire (Black)	1
48	9006348	800m/m_Computer Cable (Upper)	1
49	9006349	1300m/m_Computer Cable (Middle)	1
50	9006350	1200m/m_Computer Cable (Lower)	1
51	9006351	Power Cord	1
52	9006352	Console Assembly	1
53	9006353	Motor Top Cover	1
54	9006354	300m/m_Speed Adjustment Switch W/Cable	1
55	9006355	300m/m_Incline Adjustment Switch W/Cable	1
56	9006356	Cushion	6
57	9006357	Ø75 × 35m/m_Transportation Wheel(A)	2
58	9006358	Ø62 × Ø32 × 30m/m_, Transportation Wheel(B)	2
59	9006359	Square End Cap	2
60	9006360	305m/m_Running Belt Foot Rail	2
61	9006361	715m/m_Running Belt Foot Rail	2
62	9006362	Frame Base Cover (L)	1
63	9006363	Frame Base Cover (R)	1
64	9006364	Console Mast Cover-L	1
65	6006365	Console Mast Cover-R	1
68	9006368	Rear Adjustment Base (L)	1
69	9006369	Rear Adjustment Base (R)	1
70	9006370	Motor Cover Anchor(D)	5
71	9006371	Ø24 × Ø10 × 3T_Nylon Washer (A)	2
72	9006372	Ø50 × Ø13 × 3T_Nylon Washer (B)	4
73	9006373	Adjustment Foot Pad	2
74	9006374	Motor Bracket	1
75	9006375	Trapezoidal Safety Key	1
76	9006376	Belt Guide	2
77	9006377	Wheel Sleeve	2
78	9006378	1200m/m_Sensor W/Cable	1
80	9006380	1/2" × UNC12 × 1-1/4" _Carriage Bolt	2
81	9006381	1/2" × 1"_Hex Head Bolt	2
82	9006382	3/8" × 4-1/2"_Socket Head Cap Bolt	1
83	9006383	3/8" × 3/4"_Hex Head Bolt	1
84	9006384	3/8" × 1-1/4"_Hex Head Bolt	1
85	9006385	3/8" × 3/4"_Hex Head Bolt	4
86	9006386	3/8" × UNC16 × 2"_Flat Head Socket Bolt	2
87	9006387	5/16" × 1"_Button Head Socket Bolt	2
88	9006388	5/16" × 2-3/4"_Button Head Socket Bolt	2
89	9006389	M8 × 60m/m_Hex Head Bolt	1
90	9006390	M8 × 80mm_Socket Head Cap Bolt	2
91	9006391	M8 × 50m/m_Flat Head Countersink Bolt	4

Key	Part	Part Description	Q'ty
92	9006392	M8 × 25m/m_Flat Head Countersink Bolt	4
93	9006393	M3 × 10mm_Phillips Head Screw	1
94	9006394	M5 × 20m/m_Phillips Head Screw	3
95	9006395	M8 × 12m/m_Hex Head Bolt	2
96	9006396	5/16" × UNC18 × 42m/m_Button Head Socket Bolt	1
97	9006397	M5 × 5T_Nylon Nut	1
98	9006398	1/2" × 8T_Nylon Nut	4
99	9006399	3/8" × 7T_Nylon Nut	4
100	90063100	5/16" × 7T_Nylon Nut	3
101	90063101	M8 × 7T_Nylon Nut	1
102	90063102	3/8" × 7T_Nut	3
103	90063103	M3 × 2.5T_Nut	1
104	90063104	Ø5/16" × Ø35 × 1.5T_Flat Washer	2
105	90063105	Ø3/8" × Ø25 × 2.0T_Flat Washer	4
106	90063106	Ø3/8"× Ø19 × 1.5T_Flat Washer	4
107	90063107	Ø5 × Ø10 × 1T_Flat Washer	2
108	90063108	Ø5/16" × Ø18 × 1.5T_Flat Washer	1
109	90063109	Ø5 × Ø13 × 1.0T_Flat Washer	1
110	90063110	Ø1/4" × 19 × 1.5T_Flat Washer	4
111	90063111	\emptyset 25 × \emptyset 20 × \emptyset 16 × \emptyset 5 × 4.5H × 1.1T_Concave Washer	8
112	90063112	Ø8 × 1.5T_Split Washer	2
113	90063113	Ø10 × 1.5T_Split Washer	8
114	90063114	M3 × 1T_Split Washer	1
115	90063115	M5_Star Washer	4
116	90063116	4 × 12m/m_Sheet Metal Screw	20
117	90063117	Ø5 × 16m/m_Tapping Screw	24
118	90063118	5 × 19m/m_Tapping Screw	1
119	90063119	3.5 × 12m/m_Sheet Metal Screw	54
120	90063120	5 × 16m/m_Tapping Screw	11
124	90063124	3 × 12m/m_Tapping Screw	4
125	90063125	Ø4 × 50m/m_Flat Head Socket Bolt	2
126	90063126	3.5 × 16m/m_Tapping Screw	8
127	90063127	3 × 10m/m_Sheet Metal Screw	2
128	90063128	M5_Speed Nut Clip	2
129	90063129	3 × 8mm_Sheet Metal Screw	6
130	90063130	5/16" × 1/2"_Button Head Socket Bolt	8
131	90063131	Combinaison M5 Allen Wrench & Phillips Head	1
132	90063132	M6_L Allen Wrench	1
133	90063133	Controller Back Plate	1
134	90063134	Lubricant	1
136	90063136	Handgrip End Cap	2
137	90063137	3.5 × 32m/m_Sheet Metal Screw	8
139	90063139	3/8" × 1-3/4"_Button Head Socket Bolt	4
140	90063140	M5 × 10m/m_Phillips Head Screw	4

Key	Part	Part Description	Q'ty
145	90063145	Cushion Spacer	2
147	90063147	Top Motor Cover Plate	1
148	90063148	Pedal Cover (Top)	2
149	90063149	Pedal	2
151	90063151	1000m/m_Ground Wire	1
153	90063153	400m/m_Audio Cable	1
154	90063154	Chest Strap	1
157	90063157	Ø3.5 × 18m/m_Sheet Metal Screw	8
158	90063158	Beverage Holder	1
159	90063159	5/16" × 3/4"_Button Head Socket Bolt	4
160	90063160	Ø5 × 1.5T_Split Washer	4
175	90063175	3.5 × 16m/m_Sheet Metal Screw	8
177	90063177	Tablet Holder	1
177-1	90063177-1	Tablet Holder (Bottom)	1
177-2	90063177-2	Tablet Holder Adjustable Clip	1
177-3	90063177-3	Tablet Holder (Front)	1
177-4	90063177-4	Foam Stop, Handlebar Eye Tube	3
177-5	90063177-5	3.5 × 12m/m_Sheet Metal Screw	4

TREADMILL WARRANTY

Dyaco Canada Inc. warrants all its Sole treadmills' parts, for a period of time listed below, from the date of retail sale, as determined by sale receipt. Dyaco Canada Inc.'s responsibilities include providing new or remanufactured parts, at Dyaco Canada Inc.'s option, and technical support to our independent dealers and servicing organizations. In the absence of a dealer or service organization, these warranties will be administered by Dyaco Canada Inc. directly to a consumer. The warranty period applies to the following components:

Drive Motor Lifetime
Deck 3 Years
All Other Components 3 Years
Frame Weldments Lifetime
Labour 1 Year
Cosmetic Items* 90 Days

NORMAL RESPONSIBILITIES OF THE CONSUMER

This warranty applies only to products in ordinary household use, and the consumer is responsible for the items listed below:

- 1. The warranty registration can be completed online: Go to www.dyaco.ca/warranty.html and complete the online warranty registration.
- 2. Proper use of the treadmill in accordance with the instructions provided in this manual, including belt tracking.
- 3. Proper installation in accordance with instructions provided with the treadmill and with all local electric codes.
- 4. Proper connection to a grounded power supply of sufficient voltage, replacement of blown fuses, repair of loose connections or defects in house wiring.
- 5. Expenses for making the treadmill accessible for servicing, including any item that was not part of the treadmill at the time it was shipped from the factory.
- 6. Damages to the treadmill finish during shipping, installation or following installation.
- 7. Routine maintenance of this unit as specified in this manual.

EXCLUSIONS

This warranty does not cover the following:

- 1. CONSEQUENTIAL, COLLATERAL, OR INCIDENTAL DAMAGES SUCH AS PROPERTY DAMAGE AND INCIDENTAL EXPENSES RESULTING FROM ANY BREACH OF THIS WRITTEN OR ANY IMPLIED WARRANTY.
 - Note: Some areas do not allow the exclusion or limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you.
- 2. Service call reimbursement to the consumer. Service call reimbursement to the dealer that does not involve malfunction or defects in workmanship or material, for units that are beyond the warranty period, for units that are beyond the service call reimbursement period, for treadmill not requiring component replacement, or treadmill not in ordinary household use.
- 3. Damages caused by services performed by persons other than authorized Dyaco Canada Inc. service companies; use of parts other than original Dyaco Canada Inc. parts; or external causes such as corrosion, discoloration of paint or plastic, alterations, modifications, abuse, misuse, accident, improper maintenance, inadequate power supply, or acts of God.
- 4. Products with original serial numbers that have been removed or altered.
- 5. Products that have been: sold, transferred, bartered, or given to a third party.
- 6. Products that do not have a warranty registration card on file at Dyaco Canada Inc. Dyaco Canada Inc. reserves the right to request proof of purchase if no warranty record exists for the product.
- 7. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR PURPOSE.
- 8. Product use in any environment other than a residential setting.
- 9. Warranties outside of North America may vary. Please contact your local dealer for details.

SERVICE

Keep your bill of sale. The labour period is twelve (12) months from the date on the bill of sale. If service is performed, it is in your best interest to obtain and keep all receipts. This written warranty gives you specific legal rights. You may also have other rights that vary in different areas. Service under this

warranty must be obtained by following these steps, in order:

- 1. Contact your selling authorized SOLE dealer.
- 2. If you have any questions about your new product or questions about the warranty contact Dyaco Canada Inc. at 1-888-707-1880.
- 3. If no local service is available, Dyaco Canada Inc. will repair the parts, at Dyaco Canada Inc.'s option, within the warranty period at no charge for parts. All transportation costs, both to our factory and upon return to the owner, are the responsibility of the owner. The owner is responsible for adequate packaging upon return to Dyaco Canada Inc. Dyaco Canada Inc. is not responsible for damages that occur during shipping. Make all freight damage claims with the appropriate freight carrier. DO NOT SHIP ANY UNIT TO OUR FACTORY WITHOUT A RETURN AUTHORIZATION NUMBER. All units arriving without a return authorization number will be refused.
- 4. For any further information, or to contact our service department by mail, send your correspondence to:

Dvaco Canada Inc.

5955 Don Murie Street Niagara Falls, ON L2G 0A9

Product features or specifications as described or illustrated are subject to change without notice. All warranties are made by Dyaco Canada Inc.

^{*}Cosmetic items including, but not limited to the following: grips, console overlays, and labels/decals



Please visit us online for information about our other brands and products manufactured and distributed by Dyaco Canada Inc.



spiritfitness.ca



xterrafitness.ca



dyaco.ca/UFC/UFC-home.html



solefitness.ca



dyaco.ca/products/everlast.html



spiritfitness.ca/johnnyg.html



For more information, please contact Dyaco Canada Inc.

T: 1-888-707-1880 | 5955 Don Murie St., Niagara Falls, Ontario L2G 0A9 | sales@dyaco.ca

Dyaco Canada Inc. dyaco.ca

